

Link do produktu: <https://tkmix.pl/avacom-baterie-dla-panasonic-li-ion-37v-1100mah-41wh-p-63424.html>

Avacom baterie dla Panasonic Li-Ion, 3.7V, 1100mAh, 4.1Wh

Cena	62,75 zł
Numer katalogowy	AF0035BLX1AQ
Kod EAN	8591849031253

Opis produktu

Kompatybilna z: SAMSUNG: IA-BH125 RICOH: DB-60, DB-65 LEICA: BP-DC4-E, BP-DC4, BP-DC4-J, BP-DC4-UPANASONIC: CGA-S005, CGA-S005A, CGA-S005A/1B, CGA-S005E, CGA-S005E/1B, DMW-BCC12 FUJIFILM: NP-70 PENTAX: D-L1106 SIGMA: BP-41 **Bateria do aparatów:** FUJIFILM: Finepix F20, FinePix F40fd, FinePix F45fd, FinePix F47fd LEICA: C-LUX1, D-LUX2, D-LUX3, D-LUX 4 PANASONIC: Lumix DMC-FS1, Lumix DMC-FS2, Lumix DMC-FX01, Lumix DMC-FX01-A, Lumix DMC-FX01-K, Lumix DMC-FX01-P, Lumix DMC-FX01-S, Lumix DMC-FX01-W, Lumix DMC-FX01BB, Lumix DMC-FX01BS, Lumix DMC-FX01EB-K, Lumix DMC-FX01EB-S, Lumix DMC-FX01EB-W, Lumix DMC-FX01EF-A, Lumix DMC-FX01EF-K, Lumix DMC-FX01EF-S, Lumix DMC-FX01EF-W, Lumix DMC-FX01EG, Lumix DMC-FX01EG-A, Lumix DMC-FX01EG-K, Lumix DMC-FX01EG-S, Lumix DMC-FX01GK, Lumix DMC-FX07, Lumix DMC-FX07EF, Lumix DMC-FX07EF-S, Lumix DMC-FX07EG, Lumix DMC-FX07EGM, Lumix DMC-FX07K, Lumix DMC-FX10, Lumix DMC-FX100EF-K, Lumix DMC-FX100EF-N, Lumix DMC-FX100EF-S, Lumix DMC-FX100EG, Lumix DMC-FX100EG-K, Lumix DMC-FX100EG-S, Lumix DMC-FX100GK, Lumix DMC-FX10A, Lumix DMC-FX10EB-K, Lumix DMC-FX10EB-S, Lumix DMC-FX10EF-S, Lumix DMC-FX10EG, Lumix DMC-FX10EG-A, Lumix DMC-FX10EG-S, Lumix DMC-FX10P, Lumix DMC-FX10S, Lumix DMC-FX12, Lumix DMC-FX12EB-K, Lumix DMC-FX12EB-S, Lumix DMC-FX12EF-S, Lumix DMC-FX12EG, Lumix DMC-FX12EG-K, Lumix DMC-FX12EG-S, Lumix DMC-FX12GK, Lumix DMC-FX12K, Lumix DMC-FX12S, Lumix DMC-FX150, Lumix DMC-FX150EFK, Lumix DMC-FX150K, Lumix DMC-FX150S, Lumix DMC-FX180, Lumix DMC-FX180GK, Lumix DMC-FX180K, Lumix DMC-FX180N, Lumix DMC-FX180S, Lumix DMC-FX3, Lumix DMC-FX3EF, Lumix DMC-FX3EF-S, Lumix DMC-FX3EG, Lumix DMC-FX3EG-S, Lumix DMC-FX3EGM, Lumix DMC-FX3K, Lumix DMC-FX3S, Lumix DMC-FX50, Lumix DMC-FX50EF, Lumix DMC-FX50EG, Lumix DMC-FX50EGM, Lumix DMC-FX50K, Lumix DMC-FX8, Lumix DMC-FX8-A, Lumix DMC-FX8-K, Lumix DMC-FX8-P, Lumix DMC-FX8-S, Lumix DMC-FX8BS, Lumix DMC-FX8EBB, Lumix DMC-FX8EG-A, Lumix DMC-FX8EG-K, Lumix DMC-FX8EG-P, Lumix DMC-FX8EG-S, Lumix DMC-FX8GK, Lumix DMC-FX8GN, Lumix DMC-FX9, Lumix DMC-FX9-H, Lumix DMC-FX9-K, Lumix DMC-FX9-R, Lumix DMC-FX9-S, Lumix DMC-FX9BB, Lumix DMC-FX9BS, Lumix DMC-FX9EB-K, Lumix DMC-FX9EB-S, Lumix DMC-FX9EBS, Lumix DMC-FX9EF-K, Lumix DMC-FX9EF-S, Lumix DMC-FX9EG, Lumix DMC-FX9EG-K, Lumix DMC-FX9EG-R, Lumix DMC-FX9EG-S, Lumix DMC-FX9GK, Lumix DMC-FX9GN, Lumix DMC-LX1, Lumix DMC-LX1-K, Lumix DMC-LX1-S, Lumix DMC-LX1EG-K, Lumix DMC-LX1EG-S, Lumix DMC-LX1GK, Lumix DMC-LX1GN, Lumix DMC-LX1K-B, Lumix DMC-LX1S-B, Lumix DMC-LX2, Lumix DMC-LX2EF, Lumix DMC-LX2EF-S, Lumix DMC-LX2EG, Lumix DMC-LX2EG-K, Lumix DMC-LX2EG-S, Lumix DMC-LX2EGM, Lumix DMC-LX2K, Lumix DMC-LX2S, Lumix DMC-LX3, Lumix DMC-LX3EF-K, Lumix DMC-LX3GK, Lumix DMC-LX3K, Lumix DMC-LX3S, Lumix DMCLX1BS, Lumix DMC-LX9 PENTAX: MX-1, X90 RICOH: G600, G700, G700SE, GR, GR Digital II, GR Digital III, GR Digital IV, GX200 SIGMA: DP1 Merrill, DP2 Me, DP3 Merrill **Bateria do kamer:** SAMSUNG: HMX-R10, HMX-R10BP, HMX-R10EDC, HMX-R10SP