

Link do produktu: <https://tkmix.pl/avacom-baterie-dla-two-ways-ni-mh-6v-2000mah-126wh-p-63616.html>

Avacom baterie dla Two Ways Ni-MH, 6V, 2000mAh, 12.6Wh

Cena brutto	150,03 zł
Cena netto	121,98 zł
Numer katalogowy	AV0046BMX1AQ
Kod EAN	8591849004615

Opis produktu

Kompatybilność:BAUER/BOSCH: BA610, BA611BLAUPUNKT: AX120, AX240, AX77, AX85, AX90CAMLINK: CB60, CH01CHINON: C8B36, C8B361, C8B3662CULLMANN: 65600, 65601, 8160, 8162, 8164, 8165, 8167DURACELL: DR10, DR11ENERGY France: P20M, P40M, PAN1H, PAN2H, PAN4H, S20M, S40M, S66H, S77HSX99H, SP20M, SP40M, SP552C, SP55CFAMEART: CH150, CH150NM, DSP13, DSP18, DSP18NM, DSP24, DSP36NM, NP55, NP55NM, NP66, NP77H, NP77HNM, NVS1, NVS2H, NVS2HNMFERGUSON: VA376FIRSTLINE: BC618SPJ, BC636SPJFISHER: NP55, NP77FRIWO: VFW66, VFW90, VFW90B, VFW90HFUJI: NP55, NP77GP: VD101, VD102, VD103, VD151, VD152, VD153, VP101, VP102, VP103, VP151, VP152, VP153, VS101, VS102, VS103, VS151, VS152, VS153, VT101, VT102GRUNDIG: BP60, BP70, BP81, BP82, BP83, BP84, BP85Grundig: DSP36NM, DSP18, DSP24, DSP18NM, DSP13HAHNEL: CampackM2600, CampackM3800, CampackP2600, CampackP3800, CampackS2600, CampackS3800, SlimlineM1200, SlimlineM1900, SlimlineM3600, SlimlineP1200, SlimlineP1900, SlimlineP3600, SlimlineS1200, SlimlineS1900, SlimlineS3600HAMA: 46403, 46404, 46405, 46406, 46407, 46408, 46435, 46436, 46437, 46438ITT / NOKIA: NP552, NP554JVC: BNV10U, BNV10, BNV11U, BNV12, BNV140U, BNV14U, BNV18, BNV20, BNV22, BNV25U, BNV400, BNV60UJVC: BN-V10U, BN-V10, BN-V11U, BN-V12, BN-V140U, BN-V14U, BN-V18, BN-V20, BN-V22, BN-V25U, BN-V400, BN-V60UKYOCERA: BP150, BP1501, BP1502, BP1550, BP170LEICA: GEB111, GEB121MAGNAVOX: V80115BK01, V80116BK01, V80139BK01METZ: 96371MINOLTA: VBP600, VBP601, VBP630MITSUBISHI: BYM1, BYM2, BYU1, BYU2NIKON: NP55, NP77, NP66, NP66HOLYMPUS: NP55ORION: OB14PANASONIC: BP12, BP15, BP17, BP18, PV213A, PV214A, PV215A, PVB18, PVBP15, PVBP17, VVVB51E, VVVB52EPENTAX: NP55, NP77PHILIPS: SBC5217, SBC5220, SBC5222, SBC5226, SBC5417, SBV1511S01, SBV1551S01, SBV1561S01, V80115BK01, V80116BK01, V80139BK01, V80146BK01, V80149BK01RICOH: NP55, NP77, NP79RONY: H20, H40, H6, JP20, JP40, JP6, JPS20, JPS22, NP66, S20, S40ROWI: 6642, 6643, 6644, 6646, 6651, 6652ROWNSONIC: JP20, JP40, JP6, NP66, S20, S40SABA: A8200, CMA2SAMSUNG: NBE60, NC240, SCA12, VP-U10,VP-A20SANYO: NP55, NP77SELECO: AK2100SHARP: BT77, BT80SONY: EB55, HVL10D, HVL20K, HVL35K, NP55, NP33, NP55, NP55H, NP66, NP66H, NP68, NP77, NP77H, NP77HD, NP78, NP80, NP80D, NP90, NP98, NP99, NVL20DXTELEFUNKEN: VZ824, VZ825THOMSON: AKU400, AKU410, BP33, BP40, BP41UNOMAT: OP1PN, OP1SN, OP1XNP, OP1XS, OP2400PN, OP2400S, OP2800PN, OP2800S, OP2PN, OP2S, OP2XNP, OP2XS, OP3S, OP3XS, OP4S, OP4XS, OP5S, OP5XS, OP6S, OP7S, OP8S, OP8XS, OPX1803, OPX2003, OPX2403VARTA: V100, V110, V111, V200, V208, V210, V213, V217, V66, V67, V92VIVANCO: BP1006, BP1036, BP1506, BP1736, BP2406, BP2436, BP3306, BP4506, BP1006, BP1506, BP1506Y, BP1536Y, BP1736, BP2406, BP2436, BP3006Y, BP3036Y, MP1866, MP2016, MP2017, MP2416, MP3016Y, MP3336, MP4536**Akumulator do kamer:** AKAI:PVC20E, PVC40E, PVM2, PVM4, PVMS8, PVSC20, PVSC20E, PVSC40, PVSC40EBAUER/BOSCH:C61, C61AF, C62, C62AF, C63AF, V61, VCC506, VCC602, VCC612, VCC612AF, VCC613, VCC613AF, VCC662, VCC662AFBEAULIEU:8008, 8008PROHI, BV8BLAUPUNKT:CC824, CC834, CC835, CC844, CC855, CC856, CC866, CC874, CC875, CC894, CCR500, CCR540, CCR550, CCR570, CCR650, CCR650S, CCR800, CCR805, CCR806, CCR808, CCR808HIFI, CCR810, CCR810HIFI, CCR8110, CCR815, CCR820, CCR8200, CCR830, CCR830HIFI, CCR835, CCR835HIFI, CCR840, CCR840HIFI, CCR850, CCR8500, CCR877, CCR880H, CCR890H, CCR900, CCR9004, CR4300, CR4400, CR4500, CR4700, CR550, CR5500, CR5500S, CR6200, CR6200S, CR8110, CR8200, CR8210, CR8250, CR8300, CR8350, CR8400, CR8400HIFI, CR8500, CR8500H, CR8600, CR8600H, CR8700H, FV835, FV836, FV845, PTV8100, PTV877, SCR750SC.PENNEY: 9320300, 9321829CANON:EXI, VCX10HIECHINON:C8SC96, C8SC98URTIS MATHES:F690, F820, FVC70, FVC900, FVC10, FVC1000, GV600DAEWOO:DVM131X, DVM210PFERGUSON:FC54, FC801, FC802FISHER:F690, F820, FM80, FVC2000, FVC30, FVC4000, FVC701, FVC720, FVC730, FVC750, FVC770, FVC800, FVC880, FVC901, FVC950, FVC990, FVCP10, FVCP1000, FVCP2000, FVCP701, FVCP720, FVCP730, FVCP750, FVCP770, FVCP800, FVCP880, FVCP9000, FVCP901, FVCP950, FVCP990, FVCS2, FVHP200, FVP803FUJI:CVC600, CVT60, CVT70, F610AF, F615AF, F620AF, F650AF, F690, F820, FF60WIDE, FH80H8, M600AF, M680, M830HR, M860, M880, M890, P650, P660, P670, P680, P830, P850, V8FUJIX:8FF60, CVC600, CVT60, CVT70, F120SW, F128SW, F20, F60WIDE, F610, F615, F620, F630DE, F650, F660, F690, F810, F850, FF120, FF120SW, FF122, FF122SW, FF60, FF60WIDE, FG120, FG120SW, FG122, FG122SW, FH80, G8067, G806T, G901, H128SW, H80, H18, HP40, HP40PROJ, M600AF, M680, M830HR, M830HRH8, M660, M690, M890, P650, P660, P850, V8, V8F601, V8F615, V8F620, V8F650FUNAI:FCP100GENERAL ELECTRIC:CG690, CG695, CG696, CG697, CG800, CG805GRAETZ:SK60, TMC4888AFGRUNDIG:LC125, LC125C, LC125E, LC145, LC145E, LC175, LC175HE, LC180, LC180HE, LC210, LC210C, LC215, LC215C, LC225, LC225C, LC230, LC230E, LC232, LC232E, LC235E, LC240, LC240E, LC255, LC255C, LC255SC, LC285, LC285HE, LC310, LC310C, LC320, LC330, LC330E, LC335, LC335E, LC345, LC345E, LC360, LC360SC,

LC375HE, LC435, LC445, LC485HE, LC535E, LC575HE, LC635E, LC645E, LC80E, LCD100E, LCD80E, SVSC75, VS48, VS8000, VS800HI, VS8100, VS8150, VS8200, VS8250, VS8300, VS8320, VS8500, VS8500HI8, VS8800HI8, VSC35, VSC446, VSC46, VSC55, VSC75HITACHI:VMS8200A, VN2600AINSTANT:REPLAY ULTRA8MMITT / NOKIA:V8130, V8230, V8300, V8320, V8340, VB300, VH8440, VMO300, VX300JVC:GR315, GR315S, GR323, GR323EG, GR325, GR325S, GRAK5BKU, GRAW1, GRAW10S, GRAW1EG, GRAX230U, GRAX10, GRAX1000U, GRAX1010U, GRAX10EG, GRAX10U, GRAX15S, GRAX17, GRAX17S, GRAX2, GRAX20, GRAX200, GRAX201U, GRAX20S, GRAX210EG, GRAX210U, GRAX220U, GRAX25, GRAX25S, GRAX260EG, GRAX270, GRAX280EK, GRAX2EG, GRAX300, GRAX301, GRAX350, GRAX360EG, GRAX37, GRAX40, GRAX400, GRAX401, GRAX404U, GRAX410U, GRAX420U, GRAX430U, GRAX45, GRAX460, GRAX460, GRAX47, GRAX470, GRAX48, GRAX480, GRAX5, GRAX50, GRAX500, GRAX501, GRAX50EG, GRAX510, GRAX55, GRAX55U, GRAX5EG, GRAX60, GRAX600, GRAX606U, GRAX640, GRAX65, GRAX650, GRAX650S, GRAX657, GRAX66, GRAX660, GRAX68, GRAX7, GRAX70, GRAX700U, GRAX704, GRAX710U, GRAX720, GRAX730U, GRAX75, GRAX750U, GRAX754, GRAX75EG, GRAX760, GRAX760U, GRAX767, GRAX7EG, GRAX7U, GRAX800, GRAX808U, GRAX810U, GRAX82, GRAX820, GRAX82S, GRAX830U, GRAX840, GRAX857, GRAX900U, GRAX90U, GRAX910U, GRAX920U, GRAX92S, GRAX930U, GRAX940, GRAX941, GRAX957, GRAX970U, GRAXM205, GRAXM210, GRAXM217, GRAXM220, GRAXM225, GRAXM230U, GRAXM237, GRAXM30, GRAXM310, GRAXM317, GRAXM405, GRAXM510, GRAXM511, GRAXM710, GRAXM717, GRAXM910, GRAXM917, GRC99E, GRDVA1, GRDVF1, GRDVF20, GRDVF25, GRDVF3, GRDVF7, GREX1, GREZ1, GREZ1EG, GRFMX105S, GRFMX15, GRFMX15EK, GRFMX16, GRFMX161, GRFMX25, GRFMX333, GRFMX35, GRFMX405S, GRFMX45, GRFMX55, GRFMX555, GRFMX605, GRFMX605S, GRFMX65, GRFMX75, GRFX10, GRFX101, GRFX101S, GRFX102S, GRFX11, GRFX12, GRFX120, GRFX14, GRFX15, GRFX20, GRFX20, GRFX30, GRFX305, GRFX33, GRFX40, GRFX401S, GRFX405, GRFX43, GRFX50, GRFX505, GRFX53, GRFX60, GRFX601S, GRFX65, GRFXM105, GRFXM106EG, GRFXM16, GRFXM17, GRFXM270, GRFXM37EG, GRFXM38, GRFXM405, GRFXM66, GRHF700, GRHF705U, GRHF805, GRLT10, GRLT5, GRLT7, GRLT90, GRLT91, GRM3, GRM32S, GRM3EG, GRM3U, GRM44, GRM4U, GRM5, GRM5EG, GRM5U, GRM7, GRM7PRO, GRS90S, GRS95, GRSV3, GRSV7U, GRSX1, GRSX140, GRSX17, GRSX18EG, GRSX20, GRSX21, GRSX210, GRSX21EG, GRSX23, GRSX24, GRSX41, GRSX51, GRSX52, GRSX850, GRSX851, GRSX867, GRSX9, GRSX90, GRSX90EG, GRSX92S, GRSX950, GRSX960U, GRSXM106S, GRSXM180, GRSXM240U, GRSXM25, GRSXM26, GRSXM260, GRSXM26EG, GRSXM27, GRSXM27EG, GRSXM28, GRSXM307, GRSXM320, GRSXM321, GRSXM330U, GRSXM337, GRSXM340U, GRSXM46, GRSXM460, GRSXM46EG, GRSXM47, GRSXM470, GRSXM48, GRSXM515, GRSXM520, GRSXM525, GRSXM527, GRSXM55, GRSXM58EE, GRSXM607, GRSXM61, GRSXM62, GRSXM71, GRSXM72, GRSXM720, GRSXM730U, GRSXM737, GRSXM740U, GRSXM75, GRSXM760, GRSXM770, GRSXM81, GRSXM82, GRSXM91, GRSXM915, GRSXM92, GRSXM920, GRSXM930U, GRSXM937, GRSZ1, GRSZ7, GRSZ9KYOCERA / YASHICA:8KX1, FP150, FP1502, FP1550, FP170, HXH3E, KH150, KD1700, KD1700E, KD1700F, KD1700U, KD1700U/E, KD2010U, KD3010U, KD3030, KD3030E, KD3030U, KD5010U, KD5010U, KD5050, KD530, KD5530, KD5820, KD70E, KD8000, KD90E, KDH130, KDH150, KDH170, KDH530, KDM176, KDM710, KDM710E, KDM710F, KDM730, KDM750, KDM770, KDS530, KDS550, KDS820, KDS840, KDST90, KX1, KX11, KX90, KX90E, KX90U, KX90V, KXH1, KXH1E, KXH3, KXVI, KX11, KX1E, RDS530, RX1, RX70, RX90, MAGNAVOX CVL345, CVL610, CVL611, CVL612, CVM711, CVM610, CVM620, CVM710, CVM720MEMOREX:153, 154, 155, 158METZ:9637, 9702, 9704, 9705, 9712, 9713, 9714, 9715, 9716, 9724, 9737, 9740, 9744, 9746, 9755, 9783MINOLTA:8100, 8100E, BP975, C1, C2, C50, C503, C512, C513, C516, C516E, C518, C522, C532, C538, C542, C550, C552, C560U, C561, C562CL, C563CLS, C570, C60, C606, C606E, C618, C618E, C660, EX1, MASTERC606, V8100MITSUBISHI:HSCX1, HSCX1E, HSCX4, HSCX4E, HSCX4U, HSCX6, HSCX7, HSCX7E, HSCX7UNEC:VMA80NIKON:VN300, VN3000, VN310, VN3100, VN3200, VN3220C, VN330, VN340, VN350, VN360, VN400, VN500, VN5000, VN550, VN6000, VN700, VN7000, VN7200, VN750, VN7500, VN820, VN8200, VN830, VN8300, VN840, VN850, VN860, VN900, VN9000, VN910, VN9100, VN930, VN950, VN9500, VN960, VN9600NORDMENDE:AGEZ1U, AGEZ20, AGEZ30U, AG3, VM892, VMC100, CV303, CV350, CV360, CV361, CV361IS, CV362, CV450, CV451, CV451DC, CV460COL, CV461IS, CV462, HS751, SV350, SV450, SV550OLYMPUS:VM380, VM385, VM3000, VN5000, VX42, VX43, VX43E, VX43U, VX52, VX54, VX806, VX81, VX82, VX82U, VXC200, VXC500, VXC600, VXC600E, VXH806, VXS550ORION:VM892, VMC100PANASONIC:AG3, GRAX25U, GRAX55U, M810, MVS30, NB3CCD, NV3CCD, NV3CCD1, NVG1, NVG100, NVG100EN, NVG101, NVG101B, NVG101E, NVG120, NVG1B, NVG1E, NVG2, NVG200EN, NVG202, NVG202B, NVG202E, NVG220, NVG2B, NVG2E, NVG3, NVG303, NVG303B, NVG303E, NVG32, NVG3B, NVG3E, NVMS2B, NVMS70, NVMS70B, NVMS70E, NVMS70EG, NVMS95, NVMS950, NVMS95B, NVMS95E, NVMS95EG, NVRS50B, NVS1, NVS100EN, NVS1B, NVS1E, NVS2, NVS20, NVS20B, NVS20E, NVS5, NVS5B, NVS5E, NVS6, NVS600, NVS6B, NVS6E, NVS7, NVS700, NVS78, NVS78E, NVS7B, NVS7E, NVS7EG, NVS8, NVS800, NVS8B, NVS8E, NVS9, NVT1, PBS62, PV10, PV10B, PV10PX, PV14, PV17, PV18, PV19, PV20, PV21, PV22, PV31, PV32, PV332, PV362, PV40, PV41, PV42, PV43, PV480E, PV52, PV53, PV54, PV5630, PV8372, PVA207, PVA286, PVA306, PVA386, PVIQ203, PVIQ204, PVIQ205, PVIQ244, PVIQ303, PVIQ304, PVIQ305, PVIQ325, PVIQ403, PVIQ404, PVIQ405, PVIQ503, PVIQ504, PVIQ505, PVIQ511, PVIQ525, PVIQ604, PVL457, PVL557, PVL558, PVL578, PVL606, PVL607, PVL657, PVL658, PVL678, PVL757, PVL758, PVL857, PVL858, PVL958, PVLCD35, PVS332, PVS362, PVS372, PVS62, PVS63, PVS630, PVS64, VM539PENTAX:88E, PV100A, PV840E, PVC480, PVC480E, PVC500, PVC501E, PVC550, PVC8000, PVC8000E, PVC840E, PVC850E, PVC860E, PVC880, PVC88E, PVEM100, PVEM100A, PVEM100E, PVWR906PHILIPS:C625, CPL915, CVL345, M620, VKR6847, VKR6848, VKR6848R, VKR6853, VKR6854, VKR6870, VKR6875, VKR6878, VKR6879, VKR6880, VKR6881, VKR6890, VKR9010, VKR9015QUASAR:VM100, VM500, VM505, VM508, VM510, VM511, VM512, VM513, VM514, VM515, VM516, VM517, VM518, VM520, VM521, VM522, VM524, VM525, VM526, VM530, VM535, VM538, VM539, VM53AC, VM540, VM545, VM547, VM549, VM550, VM560, VM565, VML458RADIO SHACK:151, 152, 153, 154, 155RCA:CC1000, CC1650, CC600, CC604, CC612, CC614, CC616, CC617, CC618, CC6251, CC6271, CC6291, CC631, CC636, CC637, CC6371, CC6391, CC710, CC740, CC800, CC177, CC178, CC187, CC188, CC190, CC525, CC620, CC634, CC639, CLR200, CMR200, CMR300, CPR250, CPR300, CPR350, PRO800, PRO807, PRO808, PRO809, PRO810, PRO815, PRO820, PRO820A, PRO825, PRO830, PRO840, PRO842, PRO843, PRO844, PRO845, PRO846, PRO847, PRO850, PRO852, PRO854, PRO860, PRO865, PRO867, PRO870, PRO880, PRO880HB, PRO881HB, PRO883HB, PRO884HB, PROV600, PROV700CREVUE:65280, 65432, 66672, 67167, 67169, VIDEO800RICOH:NP99, R17C, R88, RHI8, R105, R105H, R108, R108H, R15, R15C, R16, R18H, R200, R250, R260, R500, R600, R600S, R610, R610S, R612, R615, R618, R620, R630, R630SUPER, R630S, R66, R67, R680, R800H, R808, R808H, R810, R830, R831, R840, R850, R86, R865SUPER, R860, R861, R865, R86S, R880, R880H, R880S, R88H, TF200SABA:CM1, CM10, CM11, CM2, CM4, CM5, CM6, CM9, PS12, VCE850P, VCE905P, VCH815, VM3000, VM5000, VM6946, VM6994SAMSUNG:K80, SCA20, SCA23, SCA25, SCH985, SCH996, SCL100, SCL150, SCK60, SCK70, SCK75, SCK80, SCM3, SCX800, SCX803, SCX804, SCX854, SCX904, SCX915, SCX953, SLC90, SVE27,

SVH30, SVH33, SVH815, VCE27N, VCE405P, VCE805, VCE805P, VCE806P, VCE807, VCH815, VPA12, VPA17, VPA18, VPA20, VPA21, VPA22, VPA30, VPA32, VPA50, VPA52, VPA55, VPA57, VPC27H, VPE404, VPE405, VPE807, VPE808, VPH65, VPH66, VPH68, VPJ52, VPK60, VPK65, VPK70, VPK75, VPK80, VPK85, VPL220, VPL320, VPL350, VPS50, VPU10, VPU12, VPU15SANYO:ES88, EX30P, EX70P, FA114, H100P, VEMD10, VEMD5, VEMES, VEMG1, VEMH100, VEMH1000, VEMS1, VEMS1P, VEMS2, VHM100P, VM66, VMD1, VMD10, VMD3, VMD3, VMD3P, VMD3P, VMD44, VMD5, VMD5P, VMD5P, VMD6, VMD6, VMD66, VMD66P, VMD66P, VMD6P, VMD6P, VMD8, VMD8P, VMD8P, VMES20, VMES20P, VMES77, VMES77P, VMES77P, VMES800, VMES88, VMES88, VMES88P, VMES88P, VMES99, VMES99P, VMES99P, VMEX1000, VMEX20P, VMEX22, VMEX220P, VMEX22P, VMEX25, VMEX30, VMEX30P, VMEX30P, VMEX33P, VMEX70P, VMH1000P, VMH100P, VMP5P, VMPS12, VMRZ1, VMRZ1P, VMRZ1P, VMRZ2, VMRZ2P, VMRZ2P, VMRZ2R, VMRZ3P, VMRZ5, VMRZ5PSCHNEIDER:SC110SELECO:FA114, FA116, FA117, FA118, FA122, FA124, FA126, FA128, FA129, FA129G4, FA136, SVM1900, SVM2100, SVM2200, SVM2500SHARP:VLE100U, VLE30S, VLE30U, VLE31S, VLE31E, VLE32U, VLE35U, VLE36U, VLE40S, VLE41S, VLE42U, VLE7E, VLE8E, VLH400S, VLHL100U, VLL310U, VLL40U, VLL64U, VLM6GY, VLMX4X, VLMX6U, VLMX7U, VLMX8U, VLN1X, VLN6SSIEMENS:FA144, FA146, FA156, FA164, FA164R4, FA166, FA166R4, FA179, FA194, FA229, FA230, FA244, FA256, FA259, FA264, FA266, FA266G, FA269, FA274SONY:10D, 2006I, 20K, CCD20061, CCD330E, CCD35, CCD380, CCD390, CCD401, CCD45E/WH, CCD485, CCD850, CCDEB55, CCDF150, CCDF201, CCDF250, CCDF250E, CCDF280, CCDF30, CCDF300, CCDF301, CCDF302, CCDF31, CCDF32, CCDF33, CCDF330, CCDF330E, CCDF334E, CCDF335, CCDF335E, CCDF34, CCDF340, CCDF340E, CCDF35, CCDF350, CCDF350E, CCDF355, CCDF355E, CCDF36, CCDF360, CCDF370, CCDF370E, CCDF375, CCDF375E, CCDF38, CCDF380, CCDF380E, CCDF385, CCDF385E, CCDF390, CCDF390E, CCDF40, CCDF401, CCDF402, CCDF45, CCDF450, CCDF450E, CCDF455, CCDF455E, CCDF46, CCDF46, CCDF475, CCDF50, CCDF500, CCDF500E, CCDF501, CCDF55, CCDF550, CCDF550E, CCDF555, CCDF555E, CCDF56, CCDF70, CCDF75, CCDF77, CCDF900, CCDFTR45, CCDFTR55, CCDFTR65, CCDFTR75, CCDFX200E, CCDFX270E, CCDFX300, CCDFX300E, CCDFX310, CCDFX370E, CCDFX400E, CCDFX41, CCDFX410, CCDFX410E, CCDFX500, CCDFX500E, CCDFX51, CCDFX510, CCDFX510E, CCDFX700, CCDFX700E, CCDFX710, CCDFX730, CCDFX730V, CCDFX730VE, CCDFX830V, CCDGV300, CCDGV8, CCDGV9, CCDGV9E, CCDM7, CCDM7U, CCDM7V, CCDM7V, CCDSP5, CCDSP54, CCDSP5E, CCDSP5G, CCDSP5Y, CCDSP7, CCDSP9, CCDSPKTRV8, CCDT250E, CCDTR1000, CCDTR101, CCDTR101E, CCDTR105, CCDTR105E, CCDTR14E, CCDTR150, CCDTR18, CCDTR2000E, CCDTR202E, CCDTR205, CCDTR3, CCDTR300E, CCDTR303, CCDTR303E, CCDTR305, CCDTR305E, CCDTR30S, CCDTR31, CCDTR323E, CCDTR330, CCDTR333, CCDTR333E, CCDTR340E, CCDTR350, CCDTR353E, CCDTR355D, CCDTR360E, CCDTR370, CCDTR380E, CCDTR4, CCDTR40, CCDTR400, CCDTR410, CCDTR420, CCDTR44, CCDTR440E, CCDTR45, CCDTR450, CCDTR45E, CCDTR470E, CCDTR5, CCDTR50, CCDTR500E, CCDTR501, CCDTR505, CCDTR505E, CCDTR50E, CCDTR51, CCDTR510E, CCDTR520, CCDTR530E, CCDTR54, CCDTR55, CCDTR550, CCDTR550E, CCDTR55E, CCDTR565E, CCDTR580E, CCDTR6, CCDTR60, CCDTR606E, CCDTR60E, CCDTR61, CCDTR620, CCDTR64, CCDTR65, CCDTR650, CCDTR650E, CCDTR66, CCDTR67, CCDTR680, CCDTR680E, CCDTR7, CCDTR705, CCDTR705E, CCDTR707E, CCDTR70E, CCDTR71, CCDTR730VE, CCDTR75, CCDTR750E, CCDTR75E, CCDTR76, CCDTR780, CCDTR780E, CCDTR8, CCDTR805, CCDTR805E, CCDTR808E, CCDTR81, CCDTR82, CCDTR83, CCDTR84, CCDTR86, CCDTR9, CCDTR900, CCDTR900HI8, CCDTR91, CCDTR93, CCDTR94, CCDTR96, CCDTR99, CCDTRV10, CCDTRV101E, CCDTRV11E, CCDTRV12, CCDTRV14, CCDTRV19, CCDTRV21, CCDTRV22, CCDTRV24, CCDTRV29, CCDTRV30, CCDTRV30E, CCDTRV33, CCDTRV40, CCDTRV52, CCDTRV53, CCDTRV60E, CCDTRV70E, CCDTRV73, CCDV101, CCDV11, CCDV330E, CCDV340E, CCDV350E, CCDV4, CCDV401, CCDV4330E, CCDV500, CCDV5000, CCDV5000E, CCDV550, CCDV600, CCDV6000, CCDV6000E, CCDV700, CCDV700E, CCDV701, CCDV708, CCDV800, CCDV800E, CCDV801, CCDV88, CCDV88E, CCDV89, CCDV9, CCDV90, CCDV900, CCDV900E, CCDV90E, CCDV95, CCDV95E, CCDV99, CCDV9E, CCDVX1, CCDVX1E, CCDX10, CCDX3, COMPOW/MAN, EB55, EVCX10, EVCX7, EVC3E, FX410, GV300, GV300WALKMAN, GV300E, GV8, GV8WALKMAN, GV8E, GV9, GV9WALKMAN, GV9E, GV9EWALKMAN, GVS50E, GVU5, GVU5VCR, GVU5E, M7U, MVC2000, MVC5000, S50E, SV300WATCHMAN, SVMH30, XVM30, XVMH30SUNPAK:SV10, SV11, SV12SYLVANIA:VMC260TAMRON:CX76V, CX7, CX7MUTELEFUNKEN:A1601, A1608, C1405, C1410, C1700L, C1808, C8100, VMA1601, VM6400, VM6700, VM6800, VM800, VM8000, VM8300THOMSON:CSV04P, CVM20P, VM510, VM520, VM540, VM58, VM741, VM75, VM88, VM90, VMS081UNIVERSUM:ART065109, ART065219, ART065837, ART066049, ART066378, ART066415, ART066457, ART066542, ART067598, ART067600, ART107673, ART107674VICTOR:BNV14, BNV22ZENITH:VM6400, VM6700, VM6800, VM800, VM8000**Sprzet geodezyjny**:LEICA:TPS300, TPS400, TPS700, TPS1100